

Drum change

LIQUIDTOOL.

1

Deactivate
SmartFiller

2

Take hoses from old
drum to new drum

3

Move the SmartFiller


4

Reinitialize drum
level


5

Activate
SmartFiller

Video instruction



Mobile App



Web App

